Step 2: Mark hole locations Step 1: Mark reference line Silent Close #5833 Mark reference line on the same level with the Mark hole locations by template **APPLICATIONS:** top of the drawer · For mounting to wooden drawer and cabinet. Reference line For Euro Slide or Ball Bearing slide (remove rubber hold close device on ball bearing slide). · Width of gap 10mm to 13.5mm(per side). · Option for left or right handed fixing. Step 4: Mark hole locations **Step 3:** Attach the "Body" to cabinet **Step 5:** Attach the "Follower" to drawer Template Mark hole locations by template Including Body, 1 piece Follower, 1 piece Ø4x 18mmL, 4 pieces (for mounting to cabinet) (for mounting to drawer) cut - cut Silent Close #5833 | Silent Close #5833 template template

3cm

🔭 cut

Right of cabinet

əşejdwəş

template

Left of cabinet

Left of drawer

4cm

5cm

cut

6cm

1cm

2cm

3cm

4cm

5cm

cut

6cm

Right of drawer

cut